

CASIO

Orchestrate Your Life with Rhythm and Melody!

Experience the true joys of music on a 61-key standard size keyboard with 210 different Tone Bank sounds to choose from!



TONE BANK
KEYBOARD

CT-615

Equipped with a full 61-key keyboard, 210 Tone Bank sounds, 20 true-to-life PCM auto-rhythm patterns and even the one-finger Casio Chord auto-accompaniment function, Casio's new CT-615 portable keyboard puts the keys to musical enjoyment right at your fingertips.



Tone Bank Function With 210 Different Sounds!

Casio's innovative "CD" Casio Dynamic sound source produces an outstanding selection of 210 crystal-clear Tone bank sounds. The "Tone Bank" function actually "integrates" the elements which make up the CT-615's preset sounds, to create totally new sounds that are like nothing you've ever heard before! And for quick-and-easy sound selection, the names of all 210 sounds are listed right on the CT-615's front control panel.

True-to-Life PCM Rhythm Patterns

From rock and disco to samba, waltz and even reggae, the CT-615's crisp and realistic PCM auto-rhythms keep your music right on time, with 20 different patterns to choose from. What's more, there's fingertip control for the rhythm tempo, so you can get just the right "groove".

Solo Performance Fun with Keyboard Percussion Sounds and Dual Bass Sounds!

The CT-615 is equipped with two special tone selectors that let you unleash your musical "solo" talents. Select the "Percussion" tone and the entire keyboard suddenly

becomes an arsenal of 49 realistic percussion sounds—just tap on the keys to play booming bass drums, snappy snares, cow bells and more! Or choose the "Bass tone" to literally "split" the keyboard in two, playing authentic wood bass sounds on the bass end of the keyboard and electric "slap bass" sounds on the upper half.

Three-Way Auto Accompaniment

The CT-615 gives you not just one, but three different types of auto-accompaniment which add full chords, bass lines and even accent notes! You can choose from the "Single Finger" (Casio Chord) mode, the Fingered 1 mode, and the Fingered 2 mode. In the Fingered Two mode, additional notes can be added to the auto-play accompaniment without affecting the auto-accompaniment pattern, for a realistic, personal touch.

Auto-play Demonstration Tune

Ready to hear how great the CT-615 can really sound? Just press the "Demo Tune" button and the keyboard automatically plays back a beautiful pre-programmed tune that showcases a wide array of CT-615 features, functions and sounds. The demo tune is also perfect as background music between your "live" keyboard performances.

SPECIFICATIONS

Number of keys: 61

Polyphonic: 10-note polyphonic

Preset tones: 20; Piano, Harpsichord, Vibraphone, Jazz organ, Pipe organ, Brass ens, Flute, Chorus, Jazz guitar, Bells, Funky clavi, Metallic sound, Synth ens, Percussion, Elec piano, Organ, Accordion, Strings, Synth-reed, Bass (Wood bass/Slap bass)

Tone Bank sounds: 210

Auto-rhythms: 20; Rock 1-2, 8 beat 1-2, 16 beat 1-2, Disco 1-2, Pops 1-2, Slow rock 1-2, Swing, Samba, Rossa nova, Waltz, Reggae, Tango, Beguine, March

Auto-accompaniment function: Casio Chord on/Fingered 1, 2

Terminals: Output jack, Sustain jack, AC adaptor jack

Built-in speaker: 12 cm dia

Power source: 6 D-size dry cells, AC adaptor AD-5 (option) or car adaptor CA-5 (option)

Dimensions (W × D × H): 920 × 320 × 75mm (36 1/4" × 12 5/8" × 2 15/16")

Weight: 6.5kg (14.3lbs)

**Design and specifications are subject to change without notice.*